


Infinite Possibilities

#### 4-Zone RGBW Remoter Model No.: LSC-Mi-FUT096

### **Products Key Diagram**




#### Note: \*


The button is for "Zone ON" and for engaging and disengaging function

## **Zone Controls and Capacities**

FUT-096 remote is easy to use. With the remote, all the lights can be divided into 4 zones. FUT-096 can engage unlimited number of controllers in the same zone. However, one controller can only engage up to 4 remoters







#### Note:

- 1. This remote only works with specific Mi-Light / Miboxer products; The compatible controllers are FUT037, WI5. For more controllers, contact your agents.
- 2. During the time using the remote, if the indicated lamp blinking guickly, please change new batteries.
- 3. Indoor use. Away from high humid, over room temperature, and dusty environment.
- 4. For a better performance, free electromagnetic waves and avoid a large metal objects in between the remote and controllers.

# Instructions of Engaging/Disengaging Remote and Controller

# Engaging





Power off light, after 10 seconds, power back on







Lights will slowly blink 3 times. That means the controller has engaged one of the zones of the remote FUT96





If engagement failed, please double check if the light was blinking when on step 2. Repeat the steps again if needed.

# Disengaging






Same as the step 1 of engaging, power off light, after 10 seconds, power back on.

Within 3 seconds Short press "

" button of engaged zone 5 times





If disengagement failed, please double check which zone was engaged the controller and check if the light was blinking quickly when on step 2. Repeat the steps again if needed.

