


### 3. Operating Instruction for Receiver:



### 4. Engaging The Remote (M1, M2, or M6) and The Receiver (M3-3A):

The remote and the receiver have been engaged before leaving factory. If they are unpaired accidentally, please engage the remote and the receiver.

Before engaging or disengaging, double if the power has been connected to the receiver properly. The indicator light of the receiver will be flashing.

**Engage:** Short press *ID Learning Button* on the M3-3A receiver, the indicator light will blink quickly, then press any key on the remote M1/M2/M6. The indicator light will flash several times. The remote and the Controller are engaged.

**Disengage:** Long press *ID Learning Button* on the M3-3A Receiver for 5 seconds. It will erase the previous engagement.

**Attention:** One receiver M3-3A can be engaged with max of 10 same or different kinds remote.

### 5. Wiring Diagram:

